

DOOR SWEEP REPLACEMENT

1. To remove the door open it past 90 degrees and carefully lift it off the nylon hinge pins/ Note the position of the cam faces on the pins- they must be in proper position-so that door will self-close.
2. Place door on a flat surface, face down.
3. To install new sweep by pushing the dart into the groove in the channel. The interior sweep should be at least as wide as the door opening. The length of the exterior sweep should be the same width of the door face. Make relief cut-outs at the end of each exterior sweep where it overlaps the magnetic gasket. Replace screws removed.
4. Reverse the procedure in Step 1 to reinstall door. Be certain that the nylon cams are in the same position they where in when the door was removed.
5. Be sure that your building floor the under swing radius is free of any protrusions or sharp object which may damage the sweep

