

FLOOR SCREED INSTALATION

1. A bed of caulk should be applied on each outside bottom edge between the floor and the screed to compensate for any minor irregularities in the building floor.
2. Check squareness of the corners, check dimensions and then secure the screed into position with concrete nails.

